

# Manual Thermometer Calibration

1



Fill a container with crushed ice

2



Add water to meet the top of the ice.

3



Insert thermometer stem & make sure the dimple is submerged.

4



Adjust the dial to 32°F.

Wait  
30 seconds.



**Note:** Follow manufacturers instructions to calibrate digital thermometers.